



INFORMATION BULLETIN

Date: June 6, 2014

From: Cusco Fabricators LLC.

To: All Customers of Cusco Fabricators LLC. and all users of Cusco trucks

Subject: This bulletin is intended to provide you with information regarding the safe use of the tank stand and the rear door stand on all Cusco trucks (except for low profile trucks). The door stand and tank stand are depicted pictorially in figure 1 below.

The tank stand is designed to assist in positioning the tank in the elevated position and the door stand is designed to assist in positioning the rear door in the open position. These stands are designed and constructed to be used in conjunction with the other mechanisms on the tanks, in particular the hydraulic cylinders.

Always use the tank stand and rear door stand in conjunction with their respective hydraulic cylinders, see figure 2 (items 1 and 2).

Do not use the tank stand on its own at any time, especially while personnel are performing work under or around the tank.

Do not use the door stand on its own at any time, especially while personnel are performing work inside the tank, or around the rear door.

Prior to each use, the condition and operation of the stands and hydraulic cylinders should be inspected to ensure they are in proper working condition.

DANGER: Failure to follow these instructions may result in hazardous working conditions which could increase the risk of property damage, serious personal injury or death.

WASTEQUIP CUSCO



Door stand



Tank stand

Figure 1



Figure 2